





- 1) Turn on the machine by holding the power button (■) for 3 sec



- 2) Press the arrow buttons (◀▶) to change the selected cycle




- 3) Press the button (■) to start the cycle




The 10 min cycle can be interrupted at any time by pressing the button (■) again  
The machine will automatically switch to the rinsing phase

- 4) Press the button (■) for 5 sec to enable / disable the automatic cycle startup





5) Press the button ( ) for 2 sec to access the parameters setup mode



- a) Press the button ( ) to change the parameter

Boiler temperature  
 Tank temperature  
 Short cycle time  
 Medium cycle time  
 Long cycle time

Rinsing phase length  
 Detergent dosing time for the tank  
 Detergent recovery time  
 Rinse aid recovery time

- b) Press the arrow buttons ( ) to change the parameter value

- c) Press the button ( ) to return to the main menu

6) Press the button ( ) for 2 seconds to access the information menu



- a) Press the arrow buttons ( ) to change the displayed information

Number of performed cycles Temperature of the last 20 wash cycles  
 Number of regenerations Temperature of the last 20 rinse cycles  
 Water consumption in liters Last 20 errors entries

- b) Press the button ( ) to exit the menu